

Phase II

- Put plastic down inside of cabinet and around to minimize the impact of spills.
- Use a 1/4" notched trowel to set an even mortar bed across the entire surface.
- Place all tile and set to make sure grout lines will be even. (Hint cleanup any mortar at this time.)
- Let stand for 4-5 hours. Then mix grout according to manufacturers recommendation. We needed about a quart for our install.
- Rub grout with sponge or other device into all the cracks making sure to fill the lines completely.

HINT: If you are using tile as your edging make sure that the top tile overhang the thickness of the tile plus an 1/8" for mortar. Use tape to hold the tile in place.



Drain Info:

Drain Pipe Setup with Pop Up valve and standard American hardware, which is generally included when you buy a faucet set..

- Clean the surface with Muriatic Acid if needed.
- Install Sink using a heavy bead of caulk. Cleanup the caulk with water quickly.
- Install Faucets per manufacturer directions.
- Make sure all sewer and Drain connections are made. (we had to cut our drain pipe off to 1.5". In addition don't forget Teflon tape on all threads to protect from leaking.)
- Send us your pictures.

Sonoran Copper

2955 E. Cardenas Dr.
Vail, Az 85641

Phone: 877-99 SINKS
Fax: 877-99 SINKS
E-mail: sales@sonorancopper.com



Sonoran Copper Sink Install Sheet



Jason Bartels & Chris Rust



Sink with Noche Tumbled Marble Tile.

Custom Sinks & Service

Tel: 877 -99 SINKS

Before You Start

Here is a list of required items:

1. Phillips screwdriver
2. Jig Saw
3. Tape Measure
4. Notched Trowel, Bucket, & Sponge
5. Rent a Tile Saw ~35.00



Nail Marking where to cut new top

Items to buy at your local store:

1. 3/4" Particle Board ~12.00
2. Tile Backer Board with Rubber Finish ~10.00
3. Latex Mortar ~12.00
4. Sanded Grout ~ 9.00
5. Tile (Hint don't forget to account for 3/16" grout gap)
(4.50-10.00/square foot)
6. Muratic Acid to Clean Tile ~5.00
7. Tile Sealer ~12.00

Phase I

1. Disassemble Old Countertop (Cut caulk at countertop edge with utility knife and remove screws)
2. Disconnect Water and Sewer lines from old sink.
3. Measure for new top & Cut out Particle Board to fit.
4. Now fit particle board to new space, I suggest using your old top as a guide
5. Now place your new sink on top of your particle board placing it to allow space for the overflow in front and faucets in back.
6. Create a nice size overhang for the sink to rest on by lining inside of the circle with electrical tape and drew a concentric line. We use this as our guide to cut with the jigsaw. -TEST FIT SINK-
7. Cut your tile backer board to match the new counter top. Then replicate your cutout for your sink.



Phase II

NOTE: If you are using porous tile please seal them before you secure them with mortar.

1. Now layout your tile and make sure that you have enough. Also, draw on the tiles you need to cut to fit for the **sink & Faucet**.
2. Cut ALL your tile on the Wet Saw and test fit with sink. This is your chance to buy an extra tile if you make a mistake or are short 2 like we were.
3. Mix your mortar according to the manufacture's recommendation. We needed about a 1/2 gallons worth for our



Sonoran Copper

2955 E. Cardenas Dr.
Vail, Az 85641

Phone: 877-99 SINKS
Fax: 877-99 SINKS
E-mail:
sales@sonorancopper.com